

ASPHALT ANCHORING INSTRUCTIONS by FLEXPOST®

Tools Required:

Marker
High Speed Power Drill
3/4" Masonry Drill Bit
Wide Flat Head Hammer
Socket Wrench with 15/16" Drive

Parts Included:

1 —Base Plate
4 —Mungo Plugs
4 —Hex Lag Screws
4 —Flat Washers

1



Position base plate and spring in desired anchoring location.

Mark the four base holes to be drilled.

2



Use high speed power drill with 3/4" masonry bit and core drill each hole 6" in depth.

3



Using the wide flat hammer stuff mungo plugs into core drilled holes.

4



Make sure top of mungo plug is flush with asphalt surface.

5



Place base over four holes.

Flat washer and hex screw will be used to secure base.

Using socket wrench with 15/16" drive, thread all four hex lag screws into core drilled holes.

6



Tighten hex screw until head securely holds base plate in place

****WARNING: MUST ANCHOR UNIT ON THE SAME LEVEL AS THE PARKING LOT FOR PROPER FUNCTIONALITY****



2236 112th Ave. Ste 80
Holland, MI 49424 USA

Phone: (616) 928-0829 Toll Free: (888) 307-6610 Fax: (616) 928-1138
www.flexpostinc.com