

FLEXPOST-XL™ ANCHORING INSTRUCTIONS FOR CONCRETE

Tools Required:

- Marker / Wax Pencil
- High Speed Power Drill
- 1/2" Masonry Drill Bit
- Socket Wrench with 3/4" drive
- Torque Wrench (Optional)

Parts Included:

- 1 Base Plate
- 4 Concrete Wedge Bolts
- 2 Black Set Screws
- (1) 3/16" Allen Key



- 1**
- Place base plate in desired anchoring location
 - Mark the four base holes with a wax pencil



- 2**
- Using a 1/2" masonry bit, drill 5" in depth



- 3**
- Place the base plate over the four holes and use a socket wrench or high speed drill with a 3/4" drive to thread all four bolts



- 4**
- Tighten all 4 bolts so the base plate is flush with the concrete



- 5**
- Insert the post on top of the spring, wiggle it until it is fully in the base plate



- 6**
- Insert both set screws and tighten to 100 ft. lbs. with a torque wrench or the provided 3/16" allen key to hold post securely in place
 - ** Re-torque as needed **

FLEX
POST

2236 112th Ave, Suite 80
Holland, MI 49424
616-928-0829 • www.FlexpostInc.com