

# Ultra-ADA-Pads, Composite Wet-Set Model Installation Instructions

Please read and understand all of these directions prior to installation.

1. The physical characteristics of the concrete shall be as specified in the contract documents while maintaining a slump range of 4-7 to permit the solid placement of the Ultra-ADA-Pad in the wet cement.
2. The concrete shall be poured and finished level, true and smooth to the required dimensions before placing the Ultra-ADA-Pad.
3. Place the Ultra-ADA-Pad 6-8 inches from the curb line. Working in a grid pattern, tamp the Ultra-ADA-Pad into the wet concrete using a rubber mallet and a piece of wood. Continue this process until all of the air has been released, and the Ultra-ADA-Pad surface is flush with the surrounding area. Do not strike the pad directly.
4. Following the placement, the Ultra-ADA-Pad elevation should be checked to the adjacent surface with a straight edge. The Ultra-ADA-Pad elevation should be consistent with the contract drawings and specifications. Any required adjustments must be made prior to the time when the concrete begins to set.
5. When you are confident that the Ultra-ADA-Pad is in place, and no further adjustments are needed, place a cinder block on both ends to hold the Pad in place while the concrete sets.
6. During and after the Ultra-ADA-Pad installation, as well as the concrete curing stage, no walking or external forces can be placed on the Pad . The area must be protected from pedestrian traffic until concrete is cured. The Ultra-ADA-Pad will be ready for pedestrian traffic within 1-2 hours.
7. Remove the protective plastic wrap from the surface of the pad once the concrete has set up sufficiently.
8. Be sure to brush off any excess concrete from the Pad surface using a wire brush.



[www.STOPSignsAndMore.com](http://www.STOPSignsAndMore.com)